

**TURBO JET/TURBO FAN****DEPARTURE PROCEDURES**

RWY	VNAP
ALL RWYS	A or B

Rwy 12 - Turbo-jet/Turbo-fan aircraft. No right turns west of the "LEDUC" NDB.

ARRIVAL PROCEDURES - VFR AND VISUAL APPROACH

1. Avoid flying over the town of Leduc below 5000' ASL.
2. Runway 30 - right hand circuits.