

NOISE OPERATING RESTRICTIONS

NOISE OPERATING RESTRICTIONS AND
NOISE ABATEMENT PROCEDURES

A. GENERAL

Pursuant to CAR 602.105 and CAR 602.106, Noise Operating Restrictions and Noise Abatement Procedures apply, at Toronto/Lester B. Pearson Intl Airport, to all IFR and VFR Aircraft, unless otherwise specified.

B. NOISE OPERATING RESTRICTIONS

1. RESTRICTIONS:

- a) Subject to paragraph d) or e), arrivals and departures of all aircraft are restricted as per the table below:

Aircraft	Restricted Hours - local time
Noise certification or type	Arrivals & Departures
All non-noise certificated jet aircraft	2000 - 0800
All ICAO annex 16, vol 1 chapter 2 & equivalent aircraft	0000 - 0700
All ICAO annex 16, vol 1 chapter 3 & equivalent aircraft	0030 - 0630
All other aircraft	0030 - 0630

- b) Non-noise certificated jet powered aircraft are prohibited from departing on runways 05, 06L, 06R, 15L, 15R and 33L.
- c) Between 0000 and 0630 local time, departures are prohibited on runways 05, 06L, 06R, 15L & 15R and arrivals are prohibited on runways 24R, 24L, 23, 33R, 33L and 15R unless assigned by ATC.
- d) All aircraft operating on a scheduled and repetitive basis are required to obtain an extension or an exemption to operate during the restricted hours. Submit requests for operating extensions on the day of operation to the Airport Operations Duty Manager with justification at 905-676-3030, (fax 905-676-5615). For advance exemption requests or information, make submission in writing to the

General Manager
Airsides Operations
Greater Toronto Airports Authority
Toronto Pearson International Airport
P.O. Box 6031, Toronto AMF, Ontario
L5P 1B2
(fax 416-776-3483)

- e) **ALL OTHER OPERATORS ARE REQUIRED TO OBTAIN PERMISSION TO OPERATE DURING THE RESTRICTED HOURS** by contacting the Airport Duty Manager on the day of operation at 905-676-3030.

2. Preferential runway assignment (0000 - 0630 local time).

Consistent with operational safety (ie wind, weather, runway conditions, approach aid availability etc.), ATC will assign runways in the following order of priority.

ARRIVALS: 05 15L 06L
DEPARTURES: 23 33R 24R

3. Engine Run-ups

Between 0000 - 0700 local time, maintenance run-ups are prohibited unless authorized by the Airport Operations Duty Manager (905-676-3030).

4. Training Flights

Training flights are not permitted in the Toronto Control Zone from 0000 - 0700 local time. For other times, prior permission is required from Toronto ACC Flow Management Unit (905-676-3528 or 1-800-268-4831).

NOISE OPERATING RESTRICTIONS